

Diagram of a Sampo JF-B1104L calculator. The calculator features a large LCD display at the top, a numeric keypad in the middle, and a function keypad at the bottom. Numbered callouts indicate the following components:

- 1: Points to the LCD display.
- 2: Points to the main keypad (numeric and basic function keys).
- 3: Points to the function keypad (special function keys).

- 1 太陽能電源
- 2 顯示螢幕
- 3 塑膠按鍵

[illegible]

SAMPO Joy in your life

保證書印製於說明書最後頁

請要求經銷商填妥購買日期及藥店章，以確保您的權益

聲寶桌上型計算機
使用說明書(家庭用)

JF-B1104L

User Manual

說明書尺寸：140mm x 210mm

使用說明

規格說明

- 12位數液晶顯示螢幕
 - 太陽能及電池兩種電源
- 正負值顯示
 - 8分鐘無操作自動關閉電源
- GT總和運算
 - MU損益運算

按鍵說明

- [+/-]**：正負轉換鍵
- [+]** **[-]** **[X]** **[÷]** **[=]** **[↵]**：功能鍵
- [AC]**：全部/清除鍵
- [ON/OFF]**：電源開啓/清除錯誤/清除鍵
- [←]**：退格鍵（刪除最後一位數字）

顯示說明

- GT：總計
- M (MEMORY)：獨立記憶
- (-MINUS)：負數值
- E (ERROR)：超位或錯誤，用 **[ON/C]** 鍵清除所有數值或用 **[←]** 鍵刪除位數

記憶操作

- [M+]**：記憶加法鍵（可加上螢幕上的數值並獨立記憶）
- [M-]**：記憶剪法鍵（可減去螢幕上的數值並獨立記憶）
- [MR]**：叫出記憶總值（未按 **[MC]** 鍵以前有效）
- [GT]**：總和計算，按下 **[=]** 或 **[%]** 鍵，結果會累計在總和中，按下一次可顯示總和，連續按下兩次，可清除總和。
- [MC]**：記憶清除
- [00]**：快速增“0”鍵（按一下，同時出現2個“0”）
- [MU]**：損益運算鍵

電池更換

- (1) 鬆開後蓋螺絲，並小心取下後蓋
- (2) 以螺絲刀或其它工具，將電池輕輕推出電池罩
- (3) 反向推入新電池（注意：⊕極朝上）
- (4) 以原方法裝回後蓋，並鎖上螺絲（切勿過度用力） *勿破壞電路（見圖一）
- * 本系列產品採用雙電源配置：①太陽能 ②鈕扣電池（1.5V）
- * 本機約8分鐘無操作自動關閉電源
- * 當顯示螢幕變得模糊時，表示電池快用完，您可以繼續使用，太陽能供電或者更換新電池讓顯示幕更清晰



Example 計算案例	Operation 操 作	Display 顯 示
100+50-30 (-10)x20÷0.5=	100 [+] 50 [-] 30 [=] 10 [÷] 20 [=] 0.5 [=]	GT 0. 120. -400.
5000÷3=	50 [00] [÷] 3 [=]	GT 1'666.67
5000÷3=	50 [00] [÷] 3 [=]	GT 1'666.67
5000÷3=	50 [00] [÷] 3 [=]	GT 1'666.67
\$12.34 34.56 -56.78 78.70 \$69.02	1234 [+] 3456 [+] 5678 [-] 7890 [+]	GT 12.34 46.90 -9.88 69.02
√9 x 5	9 [√] 5 [=]	GT 15.

Example 計算案例	Operation 操 作	Display 顯 示
1234567890 x 66666=	1234567890 [X] 66666 [=] [CE] [ON/C] [AC] or [ON]	ERROR 82.3037029547 0.
• 10% of 1500 (1500的10%)=	15 [00] [X] 10 [%]	GT 150.
• 1500+5%=	15 [00] [+] 5 [%]	GT 1'575.
1500-5%=	15 [00] [-] 5 [%]	GT 1'425.
• 20對500的百分比	20 [÷] 5 [00] [%]	GT 4.(%)
368+97+97=	368 [+] 97 [=]	GT 562.
839-47-47=	839 [-] 47 [=]	GT 698.
5 ⁻¹ =	5 [+] [=] [=] [=]	GT 0.0016
22.5 ³ =	22.5 [X] [=] [=]	GT 11'390.625

Example 計算案例	Operation 操 作	Display 顯 示
25 x 5 -) 84 + 3) 68 ÷ 17 182	[MC] 25 [X] 5 [M+] 84 [+] 3 [M+] 68 [÷] 17 [MU] [MR] [MC]	MEMORY 125. MEMORY 28. MEMORY 85. MEMORY 182.
123478 ÷ 5	123456 [÷] 5 [=] 78 [+] 5 [=]	123'456. 1'234. 123'478. GT 123'483.
32 x5 +4-6 79÷2-30+88 175÷3	[ON/C] 32 [X] 5 [+] 4 [-] 6 [=] 79 [÷] 2 [-] 30 [+] 88 [=] 175 [÷] 3 [=]	GT 0. GT 158. GT 97.5 GT 178. GT 433.5

Invoicing (發票)

Article (項目)	Quantity (數量)	Unit price (單價)	Discount (折扣)	Amount (總金額)
A	320	\$ 32	5 %	\$ 9'728.00
B	150	20	8 %	2'760.00
C	460	78	7 %	33'368.40
Total	930			45'856.40
5% Salestax (稅-5%)				\$ 2'292.82
Grand Total (總和)				\$ 48'149.22

MEMORY					GRAND TOTAL
320 [00] [X] 32 [=] 5 [%]					2'760.00
150 [00] [X] 20 [=] 8 [%]					33'368.40
460 [00] [X] 78 [=] 7 [%]					930.00
[GT]					45'856.40
[+] 5 [%]					48'149.22

保養方法

- 1.及時更換電池：在發現所顯示的讀數暗淡時，表示電池已經耗盡，應及時更換，如長時間不使用，應將機內電池取出，以防止電池漏液腐蝕損壞計算機。
- 2.防止擠壓、敲擊或掉落在地上，顯示的玻璃器件易破碎。
- 3.液晶顯示的計算機只能在攝氏0-40度的環境中使用，不宜在強光下使用，避免陽光中的紫外線加快液晶螢幕的老化，也不宜在濕氣過重和有腐蝕氣體的環境中使用和存放，以免損壞機件。
- 4.留意防塵，用後要裝入皮套或塑料套內，防止灰塵侵入。不可用汽油、乙醇等擦拭。